

Neo Preamp

Tube Preamp adds colors to your recordings!



Developed by



Operational Manual

The information in this document is subject to change without notice and does not present a commitment by Sound Magic Co. Ltd. The software described in this document is subject to a License Agreement and may not be copied to other media. No part of this publication may be copied, reproduced or recorded, for any purpose, without prior written permission by Sound Magic Co. Ltd. All product and company names are trademarks of their respective owners.

Sound Magic Co. Ltd

<http://www.supremepiano.com>

<http://www.soundemon.com>

support@soundemon.com

206, Min 4, People Daily, ChaoYang, Beijing

P.R.China

Version 1.0

Register Neo Preamp

Neo Preamp must be registered before it could sound.

You have to enter keycode into the text box.

First, please find the text box named Enter Your KeyCode Here



* Enter Your KeyCode Here *

Then paste the keycode into the box



%'REgP7'.vRY=gc!WR#%m'pd5\TM*u(.kJ;

Press Enter, you will see Authorized to XXXXXXXX



Authorised to Wang Yichi@Beijing

If the text box still shows the keycode, it means the keycode is not correct, You need to contact customer service to get a new keycode. Please note 95% of the failures are caused by copy one more space at the beginning or the end of the keycode.

What if YOU enter the keycode incorrectly?

The only solution for this problem is for the customer to delete the Windows Registry Entry.

Click "Start" on the windows desktop.

Click "Run" and type in 'regedit' then press enter. A window will appear.

Click the 'Edit' tab and select 'Find...' and type in "NEOMIXING "then press enter.

Right click on the folder highlighted in the Left window and select 'Delete' and click 'Yes' to confirm to delete this item.

Close the window.

Load the VST and it should show " *Enter Your KeyCode Here * "

If it does not show this message you should follow the above procedure again taking care to follow every step.

Controls

Gain: in dB. Slider Value shows the actual boost amount while Max Value shows the max boost amount under current range setting.

Respond: The respond speed of the dynamic, measured in milliseconds.

Sustain: Sustain amount for the amp, the larger, and the smoother of the sound.

Range: The Non-Linear Range of the Dynamic, Ranging from 5dB to 20dB.

Harmonic: The Amount of even Harmonic distortion.

Low: Baxandall Low Band EQ

High: Baxandall High Band EQ

Clipping Type: Choose different curves for clipping